



Dressing Stick

Materials:

- One 24 inch long, 5/8 inch dowel
- One 1-1/4 inch metal cup holder hook
- One plastic-coated hat/coat hook
- 24 inches of pipe insulation with 5/8 inch hole (optional)

Directions:

1. Pre-drill starter holes in each end of dowel.
2. Insert dowel into pipe insulation (optional).
3. Put a dab of glue in one hole of dowel.
4. Twist cup holder into hole, being careful not to split dowel.
5. Put dab of glue in open hole at other end of dowel.
6. Twist hat/coat hook into hole, being careful not to split dowel.
7. Allow to dry.





Assistive Technology Partners

BREAKING BARRIERS, CHANGING LIVES

Assistive Technology Partners
601 E. 18th Avenue, Suite 130
Denver, CO 80203
303/315-1280 Main 303/837-8964 TTY
303/837-1208 Fax 800/255-3477
www.uchsc.edu/atp

Also available in: Braille, large print, audio tape, disk and alternate language formats

Fast Facts made possible by NIDRR Grant #H224A40014